

Circle Computer, Inc.
 466 High Plain Street
 Walpole, MA 02081
info@circlecomputer.com
 PH: 508-668-8778
 FX: 508-668-9779

Lexmark Memory Guide

	Printer Name	MB	Part #	
Lexmark	LaserPrinter	1	1039136	
Lexmark	LaserPrinter E	2	1364933	1039137
		3.5	1364878	1038675
Lexmark	LaserPrinter 5E , 6, 6A, 6P 10, 10L, 10P	1	1364936	
		2	1183334	
		4	1364907	1183335
Lexmark	Laser Printer 10 R, 10P, 12R 12C, 12L,16L	2	1364921	
		4	1364877	
Lexmark	Optra R/L/N/C Series	8	1364876	
		16	1364875	Optra R/L/N C only same as 16
		32	1364874	
		2 Flash	1364922	
		4 Flash	1364879	
Lexmark	Optra S Series	2	1364921	
		4	99A0517	
		8	99A0518	
		16	99A0519	
		32	99A0520	
		64 EDO	99A0724	
		1 Flash	99A0521	
		2 Flash	99A0522	
		4 Flash	99A0523	
Lexmark	Optra T Series	4 SD Ram	5K00013	
Lexmark	Optra W Series	8 SD Ram	5K00014	
Lexmark	Optra C710/720	16 SD Ram	5K00015	
Lexmark	Optra M Series	32 SD Ram	5K00016	
		64 SD Ram	5K00017	
		128 SD Ram	5K00119	
		2 Flash	5K00115	
		4 Flash	5K00116	
		8 Flash	5K00117	
		16 Flash	5K00118	
Lexmark	Optra SC 1275	4	45H0023	
		8	45H0024	
		16	45H0025	

32	45H0026
64	45H0027
1 Flash	45H0020
2 Flash	45H0021
4 Flash	45H0022

Lexmark

Optra Color 1200

32	11G0953	pair of 16s
64	11G0954	pair of 32s
16	11G0608	1 16 simm
32	11G0609	1 32 simm