

Circle Computer, Inc.  
 466 High Plain Street  
 Walpole, MA 02081  
[info@circlecomputer.com](mailto:info@circlecomputer.com)  
 PH: 508-668-8778  
 FX: 508-668-9779

**Lexmark Service Manuals**

<b>Printer</b>	<b>Service &amp; Parts Manual</b>	<b>Service Manual / Guide</b>
Lexmark 4019 LaserPrinter Lexmark LaserPrinter E	1039671	Not Available
Lexmark 4023 W810	12G3978	12L0401
Lexmark 4025 Optra W820	12G3663	12B0000
Lexmark 4025 Optra W820 Finisher	12G3781	12B0000
Lexmark 4025 Optra W820 Options	12G3782	12B0000
Lexmark 4029 LaserPrinters 5E, 6, 6A P, 10, 10L, 10A, 10P	1183432	Not Available
Lexmark 4039 LaserPrinters 10R, 10+, 12R, 12C, 12L, 16L	1419488	1419484 ( 10P )
Lexmark 4040 Optra N	11A9985	11A9051
Lexmark 4040 Optra N Finisher	11A9935	11A9925
Lexmark 4044 Optra E310, 312	12G3613	12A2258
Lexmark 4045 M410/ M412	12G3517	4K00171
Lexmark 4049 Optra L & R	13A0329	1408818
Lexmark 4059 Optra S	12G0139	43H1702
Lexmark 4059 Optra SE 3455	12G0139	11K0900
Lexmark 4069 Optra T	12G3794	11K2280 ( cd rom)
Lexmark 4520 T520 / 522	12G3967	
Lexmark 4069 T620 / 622	12G3959	11K3100
Lexmark 5016 Optra C710	12G0234	10E0201
Lexmark 5024 Optra C720	12G3667	
Lexmark 5040 Optra SC	12C0985	11C0901
Lexmark 5045 Optra C	69G3225	69G3241
Lexmark 5050 Color 1200	12G0169	11F0801